



Thanks for your purchase and your trust.



## INSTRUCTIONS

Here are the steps to install your new pedals:

1. Submerge your new pedal pads in hot water for 15 minutes to make them easier to install
2. Remove your car existing brake pedals (the accelerator pedal can't be removed)



3. Install the new brake pedal
4. Install the new accelerator pedal directly on your existing accelerator pedal by clipping it over the old one.

If you have any questions concerning this product, contact us at [info@tesmax.ca](mailto:info@tesmax.ca)

TesmaX team

[www.tesmax.ca](http://www.tesmax.ca)



Merci pour votre achat et votre confiance.



## INSTRUCTIONS

Voici les étapes pour installer vos nouvelles pédales:

1. Faites tremper vos nouvelles pédales dans de l'eau chaude pendant 15 minutes pour les rendre plus faciles à installer
2. Retirez la pédale de frein de votre voiture (la pédale d'accélérateur ne peut être retirée)



3. Installez la nouvelle pédale de frein
4. Installez la nouvelle pédale d'accélérateur directement par-dessus la pédale d'accélérateur originale de votre voiture

Pour toute question concernant ce produit, contactez-nous à [info@tesmax.ca](mailto:info@tesmax.ca)

L'équipe TesmaX

[www.tesmax.ca](http://www.tesmax.ca)